

**You will need:**

- Level
- Tape Measure
- Pencil
- Drill/Electric Screwdriver
- Appropriate hardware and anchors for your wall type
- Masking Tape

**Installation:**

- 1 Locate studs (if applicable) and fasten bottom clips through holes A into studs (or block wall).

Note: larger boards may have 3 clips

- 2 Directly above bottom clip, fasten top clip through slotted hole B at a height 1/4" higher than board height.

- 3 Set board in place and tap top clips down to top of board. Using screws removed from step 1, fasten board through hole C on top and bottom clips.

Note: screws are self drilling, use electric drill with Robertson #2 bit.

