

Installation

Waste Receptacle Liners

Part Numbers P11-001, P11-004, P11-005, P11-006, P11-007, P11-015, P11-019, P11-020, P11-041, P11-042, P11-043 and P11-044

Installation Instructions

1. Using alcohol rub supplied, clean the surface of the waste receptacle where the hook-and-loop fastener is to be applied.
 - When installing on the Diplomat™ unit, apply hook-and-loop on all corners as well as entire front edge of waste receptacle.
2. Insert the new vinyl-coated nylon liner into the waste receptacle, aligning the corners of the liner with the corners of the receptacle.
3. Peel the plastic backing off of the hook-and-loop fastener and attach the liner to the receptacle.



Wait 24 hours for hook-and-loop fastener to cure before using the waste receptacle.



P20-134 Rev. A; ECN 12-15-002F
© 2012 Bradley
Page 1 of 1 11/28/2012



P.O. Box 309, Menomonee Falls, WI USA 53052-0309