

# Rough Opening Template

## Do Not Throw This Away!

13 7/8"

Radius  
6 15/16"

29 1/4"

### KB112-01RE Rough Opening Template

#### Step 1

Secure template over desired surface for mounting the KB112-01RE Recessed Laybed.

#### Step 2

Drill hole to start saw on inside of traced rough opening.  
Use saw to cut out rough opening.

#### Step 3

See installation instructions for more information on mounting.