

All ASI products are designed and manufactured to high quality standards to ensure many years of satisfactory service. To assure long life and beauty, products should be cleaned, protected, and maintained as described below. Maintenance methods varying from the below may forfeit any user/owner claims to warranty.

Dust particles should be removed by a vacuum cleaner.

Finger marks or light dirt spots may be removed with a pink (soft) pencil eraser - use pressure as you would to erase pencil marks from paper.

In cases where stains are impossible to eradicate, this material will accept a latex based paint as cover.

