

① OFF = FAN IS OFF

1 = 20 SEC 'ON', 6 ½ MIN 'OFF'

2 = 30 SEC 'ON', 4 ½ MIN 'OFF'

② Low Battery Indicator



③ Fan Speed: LOW MEDIUM HIGH

④ Auto fan cut-off switch

**VECTAIR**  
SYSTEMS

Vectair Systems Limited (UK)  
Unit 3 Trident Centre, Armstrong Road  
Basingstoke, Hampshire, RG24 8NU

Vectair Systems Inc. (North America)  
PO Box 11068, Memphis TN 38111

\*Patents Pending

**V-AIR**®

Distributed by


[www.AmeraProducts.com](http://www.AmeraProducts.com)

Phone: (800) 608-6568


Fax: (409) 840-5545

[info@ameraproducts.com](mailto:info@ameraproducts.com)

1



2



3

